Honeywell

Captuvo SL62

Enterprise Sled for Apple® iPad mini

Quick Start Guide

Aller à www.honeywellaidc.com pour le français.
Vai a www.honeywellaidc.com per l'italiano.
Gehe zu www.honeywellaidc.com für Deutsch.
Ir a www.honeywellaidc.com para español.
Перейти на русскоязычный сайт www.honeywellaidc.com.
Pro čeština jdi na www.honeywellaidc.com.
Pre slovenčinu choď na www.honeywellaidc.com.
Idź na stronę : www.honeywellaidc.com po quick start w języku polskim.
Türkçe için lütfen www.honeywellaidc.com sayfasını ziyaret ediniz.
Para Português, acesse www.honeywellaidc.com.br.
查看简体版请登陆 www.honeywellaidc.com。
查看繁体版请登陆 www.honeywellaidc.com.

Made for
iPad

Getting Started

The Captuvo SL62 Enterprise Sled (Agency Model: SL-ES-E) used with the Apple iPad mini tablet includes an optional integrated imager for scanning all types of bar codes. An optional magnetic stripe reader (MSR) for reading cards with magnetic stripes is also available.

*Note: Honeywell is not an authorized Apple repair center. Please return **only** your sled to us for repair. Honeywell is not liable for any non-Honeywell product shipped to our repair center.*

Note: Refer to your Apple iPad mini documentation for important product and safety information.

User Documentation

For more information about the sled and to download the sled documentation, visit www.honeywellaidc.com.

Note: Due to the availability of different models, your sled may look slightly different from the illustrations included in this document.

Front View

Audio Jack

Forward-facing Camera Access

On/Off Button

Mini USB Port (for charging)

Speaker

Volume Buttons

Home Button Access

Battery Door

Speaker

LED

Back View

Charging Contacts
(for charge base only)

Hand Strap Slot

Scan Button

Imager (optional)

Magnetic
Stripe
Reader (optional)

Hand Strap Pin

Main Camera Access

Scan Button

Inserting the Battery

⚠ *Ensure all components are dry prior to mating sleds/batteries with peripheral devices. Mating wet components may cause damage not covered by the warranty.*

⚠ *We recommend use of Honeywell Li-Ion battery packs. Use of any non-Honeywell battery may result in damage not covered by the warranty.*

⚠ *There is a danger of explosion if the batteries are incorrectly replaced. Replace the batteries with only the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the recycle program for batteries as directed by the governing agency for the country where the batteries are to be discarded.*

Battery Door

Battery

Sliding the Apple Device into the Sled

1. Remove the front cap and slide your iPad mini into the sled.

*Note: Be careful that the connectors are not accidentally damaged.*

2. Replace the front cap by tightening the two attached TORX (T6) screws. Be certain not to over tighten the screws.

Charging Using the Power Supply Adapter

Note: Use the power supply adapter that came with the Captuvo SL62 iPad mini sled to charge the iOS device and the sled simultaneously.

Note: Make sure that the connector is positioned correctly in relation to the port and is securely inserted into the sled. Dropping the sled with the connector plugged into the device could cause damage to the connector.

Charging using USB to PC

Note: Updates to sled firmware and plugins can only be made using the USB to PC cable. When the iOS device is in the sled and it is connected to a PC/laptop, only the sled charges. The iOS device cannot be charged or updated via USB.

LED Indicators

Color	Indication
Blink Red	Sled's battery power is low (8% and below); needs charging.
Blink Green	Sled's battery is charging.
Solid Green	Sled's battery is fully charged.

Demo Apps

To test scanning a bar code, download the Honeywell Price Check application from the Apple App Store[SM]. This application is for demonstration purposes only and does not process any data.

Application Software

The sleds require special application software. Please refer to www.honeywellaidc.com/iosdeveloper for information regarding software.

Reading Magnetic Stripe Cards

Installing Hand Strap

1. Hook the hand strap onto the metal pin.

2. Slide the opposite end of the hand strap through the slot at the other end of the sled.

3. Fold the strap and press the hook and loop pieces together to secure.

Installing Shoulder Strap

1. Slide the adapter through the slot at the bottom end of the sled and press the hook and loop pieces together to secure.

2. Clip the shoulder strap onto the metal D-Ring on the adapter

D-Ring Adapter

Shoulder Strap

Operating Temperature

The maximum operating temperature range for the sleds is 0°C to 35°C (32°F to 95°F).

Technical Assistance

Contact information for technical support, product service, and repair can be found at www.honeywellaidc.com.

Limited Warranty

Refer to www.honeywellaidc.com/warranty_information for your product's warranty information.

Patents

For patent information, refer to www.hsmpats.

Disclaimer